



6.1 Aileron control rod assembly



6.2 Aileron control horn assembly

~~6.2~~ 1. 8B (add words)




6.3 Aileron control installed

### FITTING FLAP SERVOS


9A ← **Stage 7**

To install the aileron servo into the wing you will need the following items:


- 9D - Servo
- Servo mounting screws and grommets as supplied with the servo.
- Servo control arm as supplied with the servo.
- Flap control rod assembly → 9E
- Low tack masking tape.




7.1 Flap control rod assembly *Frank*



Flap servo location




7.3 Flap servo position




7.4 Final flap installation

9C 7.2 - - - - -



7.5 Flap up



7.6 Flap down